

## **SOLAR PANEL INSTALLATION GUIDE**

ALPHA SUPPORT PHONE (909) 307-2320



## **Solar Panel Requirements**

Where a solar panel is used (TYB004 & TYB004 -U) it must be connected directly to the motor via the USB-C connector. Extension ports (150mm or 1.5m) must not be used in conjunction with solar panels.

The solar panel must receive direct sunlight for a minimum of 4-6 hours per day for active charging. All cells of solar panels require full sunlight exposure to the entire solar panel.

The cable connection must include the USB-C male to female connection, and this connection must be inside the hood cover, with proper installation of the heat shrink sleeve covering the connection. Formation of a drip loop within the hood to prevent water ingress. Application of silicone to seal the cable entry point in the head box.

## **Recommended Accessory**

Solar Panel Bracket for external solar panels - Part No: TYB Bracket to optimise solar panel positioning and sunlight exposure.

Internal roller blind battery motors - Internal Solar panels can be mounted to the window glass using the supplied 3M double sided tape.





